

# WAY-2C INSTALLATION ON PC

1. From the installation disk or downloaded file, double click on *way2c.msi*.
2. Read the license agreement. If you accept the terms in the license agreement click on the box, otherwise click "Cancel".
3. Click on "PC Interfaces" and select:  
    "Entire feature will be installed on local hard drive."
4. Most first-time users will also want to select "Help Files", "User's Manual", and "Samples" for installation on the local hard drive. **NOTE:** 64 bit system users should not try to install "Blobs Library"
5. When your selections are complete click on the "Next" button.
6. Click on " Install."
7. When the installation is complete click on "Finish".
8. For Windows 7, right click on the WAY-2C 3.0 desktop icon. Select "Compatibility". Select "Run this program in compatibility mode for Windows XP (Service Pack 2).
9. From the Desktop click on "WAY-2C Readme" for the latest information

## For free trial:

10. **Do NOT select "Register WAY-2C"**; doing so will terminate your evaluation period. Instead, from the desktop right click on "Evaluate WAY-2C". For XP select "Open", for Vista and Windows 7 select "Run as Administrator". You will have approximately 30 days, or until you decide to purchase and register WAY-2C, to test an almost full-featured version.
11. For the next 30 days you can start WAY-2C by clicking on the "WAY-2C 3.0" icon on the desktop. An "About" window containing the evaluation period information will appear.

## To purchase and register WAY-2C:

12. To purchase a license with USB hardware key to unlock the full power of WAY-2C, contact your vision integrator or:  
    RMA Electronics, Inc.      TEL: 781-749-9700      Email: [sales@rmaelectronics.com](mailto:sales@rmaelectronics.com)  
    35 Pond Park Rd., Unit #12      FAX: 781-749-9707      web: <http://www.rmaelectronics.com>  
    Hingham, MA 02043
13. With the hardware key available, but not plugged in to the computer, from the desktop right click on "Register WAY-2C". For XP select "Open"; for Vista or Windows 7 select "Run as administrator". Fill in the dialog box, then click "OK".
14. Insert hardware key if prompted. In pre-Vista systems let the 'Add New Hardware Wizard' run.
15. From the desktop select and run "WAY-2C 3.0". WAY-2C should start up without any hardware key warning. Click on "Help" and then "About" to verify the information is correct.

## Manual installation of hardware key:

If, for some reason WAY-2C fails to detect the hardware key after registration, you can try to install the key manually. To do this, have the key available but make sure it is not plugged in to the computer. Then:

16. Find *klkinst.exe*. (For 32 bit systems it will be in C:\Program Files\WAY-2C\WAY-2C 3.0\ .  
    For 64 bit systems it will be in C:\Program Files (X86)\WAY-2C\WAY-2C 3.0\ .)
17. Right click on *klkinst.exe*. For XP select "Open"; for Vista or Windows 7 select "Run as administrator".
18. Select USB from the install dialog box.
19. Insert hardware key when prompted.
20. (Pre-Vista systems) Let the 'Add New Hardware Wizard' run.
21. If any problems occur, search for and view the log file *kl2log.htm* for details.